

Grip and Pole

Components Required for Quick Assembly

ASSEMBLY STEPS

- Power the phone and tighten into screen holder (USB port to the right)
- Slide the gimbal into the pole-end, maintain pressure, tighten the screw
- Pin the camera to the gimbal
 - Camera faces away from the grip with the LEDs up
 - \circ Gimbal pinned to the left side of the camera with the arm below

Connect the phone to the grip with the right-angle USB 3.0 type C cable

Connect the 8-pin circular connector and coiled USB from pole to camera

POWERING STEPS

Power the phone – do this early to enable full boot-up

- Use the left-side grip switch to turn-on main power
 - \circ With a full charge three green LEDs will be visible on the camera

Press and hold gimbal power button – gimbal will rotate to home position

Press and hold the gimbal remote power – solid blue LED indicates pair

OPERATION

Press the gimbal mode button once to enter thumbstick control mode
--

- Ensure a tether between Boomcam and phone (key icon in top right)
 - $\circ~$ Unplug and replug the phone USB cable if the key isn't there
- Start the Boom Camera App